




## Canisters

- Stainless Steel
- Holds 0.8m of core
- Canister lid screws into canister body and has an o'ring seal
- 90% of all leakages occur from dirt and coal fines on o'ring and threads of canister lid and body
- Must ensure threads are kept clean of coal fines and dirt
- For quality assurance canisters are pressured tested and put under vacuum prior to providing to client
- Canister lid and body are numbered. Always ensure to put the corrected numbered lid to body



## Connecting Canister to Cylinder

- Pull neck of female coupling down and insert male coupling. Release neck of female coupling
- Male coupling should lock into place
- To remove, pull neck of female coupling down and male coupling should disconnect